



TYPE 27 REGULATOR RESET PROCEDURE

IMPORTANT

Always turn your control knob(s) off before closing off the gas cylinder

RESETTING

Should the excess flow safety device be activated, it is often possible to reset

1. Turn off the BBQ control knob(s)
2. Turn off the gas cylinder
3. Disconnect the hose from the gas cylinder
4. Turn the control knob(s) to high
5. Wait for at least 5 minutes
6. Turn off BBQ control knob(s)
7. Reconnect the hose to the gas cylinder
8. Open the gas cylinder's valve very slowly
9. Once fully open, wait for at least 1 minute
10. Light BBQ as per usual lighting instructions

NOTE: continual tripping will eventually prevent resetting from being achievable.



BBQs Plus stocks a wide range of gas fittings, and you can call BBQs Plus any time for advice.